

For detailed handling procedures and key operations, refer to the **SC-F71 Instruction Manual**.

- To prevent injury to persons, damage to the instrument and the equipment, a suitable external protection device shall be required.
- All wiring must be completed before power is turned on to prevent electric shock, fire or damage to the instrument and the equipment.
- This instrument must be used in accordance with the specifications to prevent fire or damage to the instrument and the equipment.
- This instrument is not intended for use in locations subject to flammable or explosive gases.
- Do not touch high-voltage connections such as power supply terminals, etc. to avoid electric shock.
- TLT is not responsible if this instrument is repaired, modified or disassembled by other than factory-approved personnel. Malfunction may occur and warranty is void under these conditions.

- This product is intended for use with industrial machines, test and measuring equipment. (It is not designed for use with medical equipment and nuclear energy plant.)
- This is a Class A instrument. In a domestic environment, this instrument may cause radio interference, in which case the user may be required to take additional measures.
- This instrument is protected from electric shock by reinforced insulation. Provide reinforced insulation between the wire for the input signal and the wires for instrument power supply, source of power and loads. Be sure to provide an appropriate ground control circuit for the following:
 - If input/output or signal lines within the building are longer than 30 meters
 - If input/output or signal lines leave the building, regardless the length.
- This instrument is designed for installation in an enclosed instrumentation panel. All high-voltage connections such as power supply terminals must be enclosed in the enclosure.
- All precautions described in this manual should be taken to avoid damage to the instrument or equipment. If the equipment is used in a manner not specified by the

Copyright © 2021 by TLV CO., LTD. ALL rights reserved (T

- All manufacturing, the protection provided by the equipment may be impaired.
- Any wiring must be in accordance with local codes and regulations.
- To prevent instrument damage as a result of failure, protect the power line and the input/output lines from high currents with a suitable overcurrent protection device with adequate breaking capacity such as a fuse, circuit breaker, etc.
- A malfunction in this product may occasionally make control operations impossible or prevent alarm outputs, resulting in a possible hazard. Take appropriate measures at the end use to prevent hazards in the event of malfunction.
- Prevent metal fragments or lead wire scraps from falling inside instrument case to avoid electric shock, fire or malfunction.
- Tighten each terminal screw to the specified torque found in the manual to avoid electric shock, fire or malfunction.
- For proper operation of this instrument, provide adequate ventilation for heat dissipation.
- Do not connect wires to unused terminals as this will interfere with proper operation of the instrument.
- Turn off the power supply before cleaning the instrument.
- Use a soft, dry cloth to remove stains from the instrument. Do not use a volatile solvent such as paint thinner to clean the instrument. Deformation or discoloration may occur.
- To push damage to the instrument display, do not rub with an abrasive material or avoid the front panel with a hard object.

- This manual assumes that the reader has a fundamental knowledge of the principles of electricity, process control, computer technology and communications.
- The figures, diagrams and numeric values used in this manual are only for explanation purpose.
- TLY is not responsible for any damage or injury that is caused as a result of using this instrument, instrument failure or indirect damage.
- TLY is not responsible for any damage and/or injury resulting from the use of instruments made by imitating this instrument.
- Periodic maintenance is required for safe and proper operation of this instrument.
- Some components have a limited service life, or characteristics that change over time. Even though these are marked as "limited life" components, all information contained herein TLY makes no warranty, expressed or implied, with respect to the accuracy of the information. The information in this manual is subject to change without prior notice.
- No portion of this document may be reprinted, modified, copied, transmitted, digitized, stored, processed or retrieved through any mechanical, electronic, optical or other means without prior written approval from TLY.
- Various symbols are used on the equipment and the manual. They have the following meaning.
 - Alternating current Reinforced insulation Δ: Safety precaution
- This symbol is used where the instruction manual needs to be consulted for the safety of both the operator and the equipment. Carefully read the cautions in this manual before using the instrument.

Copyright © 2021 by TLV CO., LTD. ALL rights reserved (T

Measured input 1

TC

RTD

Voltage/Current

A sensor power supply is not included with this product. When using voltage/current signals as measured input, use a power supply that conforms to the sensor specifications.

Copyright © 2021 by TLV CO., LTD. ALL rights reserved (T)

Figure 1 shows a 16-channel signal generator module. The module features a digital display at the top showing '0.000' and '0.000'. Below the display are several buttons and a row of 16 channels, each with a small LED indicator and a control knob. The module is labeled with '16-CH' and '100MHz'. Numbered callouts (1) through (17) point to various components: (1) points to the top left corner; (2) points to the top right corner; (3) points to the bottom right corner; (4) points to the bottom left corner; (5) points to the top left corner; (6) points to the top right corner; (7) points to the bottom right corner; (8) points to the bottom left corner; (9) points to the top left corner; (10) points to the top right corner; (11) points to the bottom right corner; (12) points to the bottom left corner; (13) points to the top left corner; (14) points to the top right corner; (15) points to the bottom right corner; (16) points to the bottom left corner; (17) points to the top left corner.

(1)	Measured value (PV) display [Yellow-green]	Displays Measured value (PV) or various parameter symbols.
(2)	Memory area display [White]	Displays the memory area No. (1 to 16)
(3)	Loader communication connector	Setting and monitoring on a computer (PC) is possible if the controller is connected with a cable to a PC via RKC USB communication converter COM-KG or COM-K2 (sold separately). The communication software PROTEM-T [™] must be installed on the PC. *For the COM-KG and COM-K2, consult TLV **Download links can be found at: https://www.tlv.com
(4)	SET key	Used in calling up parameters and set value registration.
(5)	Shift key	Shifted digits when settings are changed. Used to switch the modes.
(6)	Down key	Decreases numerals.
(7)	Up key	Increases numerals.
(8)	R.SET key	The parameters can be scrolled backwards.
(9)	MONI key	Used to switch screens. When the MONI key is pressed while any screen other than MONITOR & SV setting mode is displayed, the screen returns the PV/SV Monitor.
(10)	AREA key	When the AREA key is pressed, the screen is switched to the Memory area transfer screen.
(11)	FUNC key	The shifted function can be assigned to this key ¹⁾ for a direct access to it.
(12)	OUT1 to 3 lamp [White]	Lights when Outputs 1 to 3 (OUT1 to 3) ²⁾ are turned on.
	DO1 to 4 lamp [White]	Lights when Digital outputs 1 to 4 (DO1 to 4) ³⁾ are turned on.
	ALM lamp [Red]	Lights when any of the following occurs. • Event 1 to 4 • Input error ³⁾ of input 1 or 2
(13)	Set display (SV) display [Orange]	Displays Set value (SV) or various parameter set values.

Copyright © 2021 by TLV CO., LTD. ALL rights reserved (T)

Power ON →

Model: SCA-17

1. **11 NP** Input type for Input 1
(Refer to the Input type symbol table)
Automatically switches after displaying for 1 sec.

2. **2000** Input 1 Input range high
Input 1 Input range low
Automatically switches after displaying for 1 sec.

3. **21 NP** Input type for Input 2
(Refer to the Input 1 for the displayed contents.)
Automatically switches after displaying for 1 sec.

4. **2000** Input 2 Input range high
Input 2 Input range low
Automatically switches after displaying for 1 sec.

(When the Blind function is activated) **Auto** → Continued to

Auto → Continued to <A>


Input type symbol									
Symbol	U	J	T	S	R	E	B	N	PL II
Input type	TC								
	K	J	T	S	R	E	B	N	PL II

Symbol	U	U	L	PR	PT	JP	U	I
Input type	TC					RTD		
	W5Re/W26Re	U	L	PR40-20	PT100	JP100	Voltage	Current

Copyright © 2021 by TLV CO., LTD. ALL rights reserved (T)

Parameters in the Engineering mode should be set according to the application before setting any parameters related to operation. Once the Parameters in the Engineering mode are set correctly, no further changes need to be made to parameters for the same application under normal conditions. If they are changed unnecessarily, it may result in malfunction or failure of the instrument.

TLV will not bear any responsibility for malfunction or failure as a result of improper changes in the Engineering mode.



Copyright © 2021 by TLV CO., LTD. ALL rights reserved (T)

173 0570041-04 (00-574) 03 December 2004 Copyright © 2004 by TMI CO., LTD. All rights reserved.

Copyright © 2021 by TLV CO., LTD. ALL rights reserved (T

the valve coefficient plate or tag.

Copyright © 2021 by TLV CO., LTD. ALL rights reserved (T)

1. **A**
00 23

- Press the **ENT** key once to complete the registration of A, then the valve coefficient b will be displayed.

1. **b**
0000

- Follow the instructions to register valve coefficient values b, C, d, E, and F in the same way.

Fn53 will display other values except A to F, however the initial values can be used as is. Change these as necessary after observing the control results. Refer to the manual SC-F71 Instruction Manual [Parameters/Functions] (172-65710) for other detailed setting examples.

- Press the **MONI** key or **ENT** + **<MODE>** key to return to **<A>**: Monitor and SV setting mode.


172-65706M-04 (SC-F71) 23 December 2021

Copyright © 2021 by TLV CO., LTD. All rights reserved (T)

6. SETTING THE SET VALUES (SV)

Set value (SV) is the control target value. Register the Set value (SV)

Set the Set value (SV) to 200



- To return to the top of the list, press the **<MONI>** key or the **ENT** key until the first parameter is displayed.

172-65706M-04 (SC-F71) 23 December 2021


Copyright © 2021 by TLV CO., LTD. All rights reserved (T)

7. SET AUTOTUNING (AT)

The Auto tuning (AT) function automatically measures, computes and sets the optimum PID values. This function is unnecessary if setting the PID values manually or for pressure control by MC-COS or MC-COSR.

Set Autotuning (AT)

<A>: Monitor & SV setting mode




172-65706M-04 (SC-F71) 23 December 2021

Copyright © 2021 by TLV CO., LTD. All rights reserved (T)


8. RUN/STOP TRANSFER

The control is switched between RUN and STOP. When stopped (in STOP), control output cannot be performed in manual mode. The instrument must be stopped before attempting the setting in the Engineering mode.

Change from RUN to STOP



Start the control (RUN)



- When switching between RUN/STOP, press the **ENT** or **ENT** key, and when the mode has switched, either RUN→STOP / STOP→RUN will be displayed.


172-65706M-04 (SC-F71) 23 December 2021

Copyright © 2021 by TLV CO., LTD. All rights reserved (T)

9. AUTO/MANUAL TRANSFER

The control mode is switched between AUTO and MANUAL.

Switching to Manual mode



Perform the same steps when switching from manual mode to auto mode when **MAN1** is displayed, press the **ENT** key to switch to auto mode.

Manipulated output value setting in manual mode



- Press the **ENT** key to increase the Manipulated output value (MV).
- Press the **ENT** key to decrease the Manipulated output value (MV).
- If the **ENT** or **ENT** key is kept pressing, the changing rate of the Manipulated output value (MV) will be accelerated.
- The output value adjusted with the **ENT** and **ENT** keys will be available immediately.


172-65706M-04 (SC-F71) 23 December 2021

Copyright © 2021 by TLV CO., LTD. All rights reserved (T)

10. MEMORY AREA TRANSFER

The memory area to be used for control (control area) can be switched to the desired area.


Change control area from No. 1 to No. 2



Outline of memory area

The memory area function is to store up to 16 areas (patterns) of parameters such as a Set value (SV). This parameter can be found in the **<F>**: Parameter setting mode. Any one area out of 16 areas can be called up for the control.

F: Parameter groups in Parameter setting mode




- One memory area consists of six parameter groups.
- To change a memory area number to another, when a certain parameter is displayed, press the **<MODE>** key to shift the flashing digit to the left until the flashing digit reaches the AREA digit.

[Example: Memory area transfer of set value (SV)]

172-65706M-04 (SC-F71) 23 December 2021

Copyright © 2021 by TLV CO., LTD. All rights reserved (T)



Service

For Service or Technical Assistance: Contact your TLV representative or your regional TLV office.

In Europe:
Germany
U.K.
France
In North America:
In Mexico and Latin America:
In Oceania:
In East Asia:
Singapore
China
Malaysia
Thailand
Korean
In the Middle East:
In Other Countries:
Manufacturer:

Tel: [49-(0)7263-9150-0
Tel: [44-(0)1242-227223
Tel: [33-(0)4-72482222
Tel: [1]-704-597-3070
Tel: [52]-55-5359-7949
Tel: [61-(0)3-8973 5610
Tel: [65]-6747 4600
Tel: [86-(0)21-6462-8622
Tel: [60]-3-8065-2928
Tel: [66]-2-693-3799
Tel: [82-(0)31-726-2105
Email: sales-me@tlv.co.jp
Tel: [81-(0)79-427-1818
Tel: [81-(0)79-422-1122

172-65706M-04 (SC-F71) 23 December 2021

Copyright © 2021 by TLV CO., LTD. All rights reserved (T)

TLV EXPRESS LIMITED WARRANTY

Subject to the limitations set forth below, TLV CO., LTD., a Japanese corporation ("TLV"), warrants that products which are sold by it, TLV International Inc. ("TII") or one of its group companies excluding TLV Corporation (a corporation of the United States of America), (hereinafter the "Products") are designed and manufactured by TLV, conform to the specifications published by TLV for the corresponding part numbers (the "Specifications") and are free from defective workmanship and materials. The party from whom the Products were purchased shall be known hereinafter as the "Seller". With regard to products or components manufactured by unrelated third parties (the "Components"), TLV provides no warranty other than the warranty from the third party manufacturer(s), if any.

Exceptions to Warranty

This warranty does not cover defects or failures caused by:

- improper shipping, installation, use, handling, etc., by persons other than TLV, TII or TLV group company personnel, or service representatives authorized by TLV; or
- disinfectants or forces of nature or Acts of God; or
- abuse, abnormal use, accidents or any other cause beyond the control of TLV, TII or TLV group companies; or
- improper storage, maintenance or repair; or
- operation of the Products not in accordance with instructions issued with the Products or with accepted industry practices; or
- use for a purpose or in a manner for which the Products were not intended; or
- use of the Products in a manner inconsistent with the Specifications; or
- use of the Products with Hazardous Fluids (fluids other than steam, air, water, nitrogen, carbon dioxide and inert gases (helium, neon, argon, krypton, xenon and radon)); or
- failure to follow the instructions contained in the TLV instruction Manual for the Product.

Duration of Warranty

This warranty is effective for a period of one (1) year after delivery of Products to the first end user. Notwithstanding the foregoing, asserting a claim under this warranty must be brought within three (3) years after the date of delivery to the initial buyer if not sold initially to the first end user.

ANY IMPLIED WARRANTIES NOT NEGATED HEREBY WHICH MAY ARISE BY OPERATION OF LAW, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE AND ANY EXPRESS WARRANTIES NOT NEGATED HEREBY, ARE GIVEN SOLELY TO THE INITIAL BUYER AND ARE LIMITED IN DURATION TO ONE (1) YEAR FROM THE DATE OF SHIPMENT BY THE SELLER.

Exclusive Remedy

THE EXCLUSIVE REMEDY UNDER THIS WARRANTY, UNDER ANY EXPRESS WARRANTY OR UNDER ANY IMPLIED WARRANTIES NOT NEGATED HEREBY (INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE), IS REPLACEMENT, PROVIDED: (a) THE CLAIMED DEFECT IS REPORTED TO THE SELLER IN WRITING WITHIN THE CLAIMED PERIOD, INCLUDING A DETAILED WRITTEN DESCRIPTION OF THE CLAIMED DEFECT AND HOW AND WHEN THE CLAIMED DEFECTIVE PRODUCT WAS USED; AND (b) THE CLAIMED DEFECTIVE PRODUCT AND A COPY OF THE PURCHASE INVOICE IS RETURNED TO THE SELLER, FREIGHT AND TRANSPORTATION COSTS PREPAID, UNDER A RETURN MATERIAL AUTHORIZATION AND TRACKING NUMBER

172-65706M-04 (SC-F71) 23 December 2021

Copyright © 2021 by TLV CO., LTD. All rights reserved (T)

ISSUED BY THE SELLER. ALL LABOR COSTS, SHIPPING COSTS, AND TRANSPORTATION COSTS ASSOCIATED WITH THE RETURN OR REPLACEMENT OF THE CLAIMED DEFECTIVE PRODUCT ARE SOLELY THE RESPONSIBILITY OF BUYER OR THE FIRST END USER. THE SELLER RESERVES THE RIGHT TO INSPECT ON THE FIRST END USER'S SITE ANY PRODUCTS CLAIMED TO BE DEFECTIVE BEFORE ISSUING A RETURN MATERIAL AUTHORIZATION. SHOULD SUCH INSPECTION REVEAL, IN THE SELLER'S REASONABLE DISCRETION, THAT THE CLAIMED DEFECT IS NOT COVERED BY THIS WARRANTY, THE PARTY ASSERTING THIS WARRANTY SHALL PAY THE SELLER FOR THE TIME AND EXPENSES RELATED TO SUCH ON-SITE INSPECTION.

Exclusion of Consequential and Incidental Damages

IT IS SPECIFICALLY ACKNOWLEDGED THAT THIS WARRANTY, ANY OTHER EXPRESS WARRANTY NOT NEGATED HEREBY, AND ANY IMPLIED WARRANTY NOT NEGATED HEREBY, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, DO NOT COVER, AND NEITHER TLV, TII NOR ITS TLV GROUP COMPANIES WILL, IN ANY EVENT BE LIABLE FOR, INCIDENTAL OR CONSEQUENTIAL DAMAGES, INCLUDING, BUT NOT LIMITED TO LOST PROFITS, THE COST OF DISASSEMBLY AND SHIPMENT OF THE DEFECTIVE PRODUCT, INJURY TO OTHER PROPERTY, DAMAGE TO BUYER'S OR THE FIRST END USER'S PRODUCT, DAMAGE TO BUYER'S OR THE FIRST END USER'S PROCESSES, LOSS OF USE, OR OTHER COMMERCIAL LOSSES, WHERE, DUE TO OPERATION OF LAW, CONSEQUENTIAL AND INCIDENTAL DAMAGES UNDER THIS WARRANTY, UNDER ANY OTHER EXPRESS WARRANTY NOT NEGATED HEREBY OR UNDER ANY IMPLIED WARRANTY NOT NEGATED HEREBY (INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE) CANNOT BE EXCLUDED, SUCH DAMAGES ARE EXPRESSLY LIMITED IN AMOUNT TO THE PURCHASE PRICE OF THE DEFECTIVE PRODUCT. THIS EXCLUSION OF CONSEQUENTIAL AND INCIDENTAL DAMAGES, AND THE PROVISION OF THIS WARRANTY LIMITING REMEDIES HEREUNDER TO REPLACEMENT, ARE INDEPENDENT PROVISIONS, AND ANY DETERMINATION THAT THE LIMITATION OF REMEDIES FAILS OF ITS ESSENTIAL PURPOSE OR ANY OTHER DETERMINATION THAT EITHER OF THE ABOVE REMEDIES IS UNENFORCEABLE, SHALL NOT BE CONSTRUED TO MAKE THE OTHER PROVISIONS UNENFORCEABLE.

Exclusion of Other Warranties

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, AND ALL OTHER WARRANTIES, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE EXPRESSLY DISCLAIMED.

Severability

Any provision of this warranty which is invalid, prohibited or unenforceable in any jurisdiction shall, as to such jurisdiction, be ineffective to the extent of such invalidity, prohibition or unenforceability without invalidating the remaining provisions hereof, and any such invalidity, prohibition or unenforceability in any such jurisdiction shall not invalidate or render unenforceable such provision in any other jurisdiction.

172-65706M-04 (SC-F71) 23 December 2021

Copyright © 2021 by TLV CO., LTD. All rights reserved (T)