

INSTRUCTION MANUAL

Keep this manual in a safe place for future reference

TLV® TEMPERATURE CONTROL STEAM TRAP LEX3N-TZ

LEX3N-TZ



Manufacturer

TLV® CO., LTD.

881 Nagasuna, Noguchi, Kakogawa, Hyogo 675-8511, Japan

Tel: [81]-(0)79-427-1800 Fax: [81]-(0)79-422-2277

Copyright (C) 2024 by TLV CO., LTD. All rights reserved.

EAC



Introduction

Before beginning installation or maintenance, please read this manual to ensure correct use of the product. Keep the manual in a safe place for future reference.

The inline repairable LEX3N-TZ temperature control steam trap with built-in scale removal function is suitable for the accurate control of condensate discharge temperatures for applications with operating pressures up to 4.6 MPaG (650 psig).

DO NOT USE on any application **except** steam tracing lines, storage tank coils, instrument enclosures, steam trap air venting, and freeze protection of condensate line.

Note: The LEX3N-TZ can only control the temperature of condensate discharge from the trap; it cannot control product temperature nor the temperature of condensate backing up in the system.


1 MPa = 10.197 kg/cm², 1 bar = 0.1 MPa


For products with special specifications or with options not included in this manual, contact TLV for instructions.


The contents of this manual are subject to change without notice.


1. Safety Considerations


- Read this section carefully before use and be sure to follow the instructions.
- Installation, inspection, maintenance, repairs, disassembly, adjustment and valve opening/closing should be carried out only by trained maintenance personnel.
- The precautions listed in this manual are designed to ensure safety and prevent equipment damage and personal injury. For situations that may occur as a result of erroneous handling, three different types of cautionary items are used to indicate the degree of urgency and the scale of potential damage and danger: DANGER, WARNING and CAUTION.
- The three types of cautionary items above are very important for safety; be sure to observe all of them, as they relate to installation, use, maintenance, and repair. Furthermore, TLV accepts no responsibility for any accidents or damage occurring as a result of failure to observe these precautions.

 Indicates a DANGER, WARNING or CAUTION item.


 **DANGER** Indicates an urgent situation that poses a threat of death or serious injury.

 **WARNING** Indicates that there is a potential threat of death or serious injury.


 **CAUTION** Indicates that there is a possibility of injury, or equipment/product damage.

 CAUTION	Install properly and DO NOT use this product outside the recommended operating pressure, temperature and other specification ranges. Improper use may result in such hazards as damage to the product or malfunctions, which may lead to serious accidents. Local regulations may restrict the use of this product to below the conditions quoted.
	Take measures to prevent people from coming into direct contact with product outlets. Failure to do so may result in burns or other injury from the discharge of fluids.
	Always wear heat-insulated gloves when handling products with high body temperatures, such as when in operation. Failure to do so may result in burns.

Continued on the next page

 CAUTION	<p>When disassembling or removing the product, wait until the internal pressure equals atmospheric pressure and the surface of the product has cooled to room temperature. Disassembling or removing the product when it is hot or under pressure may lead to discharge of fluids, causing burns, other injuries or damage.</p>
	<p>Be sure to use only the recommended components when repairing the product, and NEVER attempt to modify the product in any way. Failure to observe these precautions may result in damage to the product or burns or other injury due to malfunction or the discharge of fluids.</p>
	<p>Do not use excessive force when connecting threaded pipes to the product. Over-tightening may cause breakage leading to fluid discharge, which may cause burns or other injury.</p>
	<p>Use under conditions in which no water hammer will occur. The impact of water hammer may damage the product, leading to fluid discharge, which may cause burns or other injury.</p>

2. Specifications



* Maximum allowable pressure (PMA) and maximum allowable temperature (TMA) are PRESSURE SHELL DESIGN CONDITIONS, **NOT** OPERATING CONDITIONS.

** Valve No. is displayed for products with options. This item is omitted from the nameplate when there are no options


*** Set pressure and set temperature are the initial settings when shipped from the factory.



To avoid malfunctions, product damage, accidents or serious injury, install properly and **DO NOT** use this product outside the specification range. Local regulations may restrict the use of this product to below the conditions quoted.

3. Configuration

LEX3N-TZ




No.	Description	M	R	No.	Description	M	R
1	Body			11	Snap Ring		✓
2	Cover			12	Spring Pin		✓
3	Valve Stem	✓		13	Seal Ring	✓	✓
4	Adjusting Screw			14	Screen		✓
5	Bimetal Element	✓		15	Locknut		
6	Washer		✓	16	Cap Nut		
7	Valve Seat	✓	✓	17	Cover Gasket	✓	✓
8	Valve Seat Gasket	✓		18	Nameplate		
9	Overexpansion Spring		✓	19	Spring Guide		✓
10	Return Spring		✓	20	Thrust Plate		✓
				21	Cap Nut Gasket	✓	✓

Replacement parts are available only in the following kits:
M = Maintenance Kit; R = Repair Kit

- (A) **CAUTION** DO NOT REMOVE WHILE TRAP IS UNDER PRESSURE
- (B) **CAUTION** DO NOT REMOVE CAP NUT OR COVER WHILE TRAP IS UNDER PRESSURE. Allow trap body temperature to cool to room temperature before removing cap nut or cover. Failure to do so may result in burns or other injury. READ INSTRUCTION MANUAL CAREFULLY.


4. Exploded View



5. Applications

- **DO NOT USE** on any application **except** steam tracing lines, storage tank coils, instrument enclosures, steam trap air venting, and freeze protection of condensate lines.
- **SUITABLE** for steam tracing lines or storage tank coils **ONLY IF** the required product viscosity will be maintained when the condensate is sub-cooled at least 15 °C (27 °F), even to the point of the condensate having a lower temperature than the product temperature.
- **SUITABLE** for use on instrument enclosures **ONLY IF** the steam or condensate temperature in the enclosures will **NOT** damage the instrument.
- **SUITABLE** for use as an external air vent for TLV steam traps, or as a non-freeze valve for freeze protection of condensate lines.

6. Proper Installation



CAUTION

- Installation, inspection, maintenance, repairs, disassembly, adjustment and valve opening/closing should be carried out only by trained maintenance personnel.
 - Take measures to prevent people from coming into direct contact with product outlets.
 - Install for use under conditions in which no water hammer will occur.
1. Before installation, be sure to remove all protective seals.
 2. Before installing the product, blow out the inlet piping to remove any piping scraps, dirt and oil. Close the inlet valve after blowdown.
 3. Verify that piping is of a suitable diameter.
 4. Install in a place where caution plates (including cap) can clearly be seen during periods of maintenance, in the lowest part of the pipeline so that condensate flows into the trap by gravity.
 5. Install the product so that the arrow on the body is pointing in the direction of condensate flow.
 6. The trap may be installed either horizontally or vertically. However, when installing horizontally, make sure that the trap is installed with the temperature adjusting screw positioned higher than the piping in which the trap is installed. (Upside-down installation is not permissible.)
 7. When used as an automatic non-freeze valve, do not use thin-walled tubing for outlet piping. As freezing occurs on outlet side, use a short, thick-walled pipe to discharge to atmosphere.
 8. When used as an external air vent for TLV steam traps, connect to the top of the steam trap.
 9. Install inlet and outlet valves to isolate the product in event of trap failure or maintenance.
 10. If the product is subject to back pressure, install a check valve.
 11. Open the inlet valve gradually and check to make sure that the product functions properly.

7. Operational Check


A visual inspection can be carried out to aid in determining the necessity for immediate maintenance or repair, if the trap is open to atmosphere. If the trap does not discharge to atmosphere, use diagnostic equipment such as a stethoscope, thermometer or TLV TrapMan (within its pressure and temperature measurement range).

Normal:	Condensate is being discharged from the discharge outlet. (The surface temperature of the trap should be about 10 to 20 °C (20 to 40 °F) lower than the set temperature.)
Blocked:	No condensate is discharged and the surface temperature of the trap is low.
Blowing:	Live steam continually flows from the outlet and there is a continuous hissing sound of flow. The surface temperature of the trap is higher than the set temperature.

(When conducting a visual inspection, flash steam is sometimes mistaken for steam leakage. For this reason, the use of a steam trap diagnostic instrument such as TLV TrapMan is highly recommended.)

8. Adjusting Temperature Setting

The temperature setting can be easily adjusted.



- To prevent possible injury, always relieve pressure from trap before opening to adjust the temperature setting.
- Always wear heat-insulated gloves and eye protection when handling products exposed to high temperatures. Failure to do so may result in burns.


Instructions for Adjusting Temperature Setting

1. First close the external valve from which the steam and condensate flow to the trap (the "inlet isolation valve"), followed by then closing the external valve to which the condensate flows from the trap (the "outlet isolation valve"). Wait until the pressure between the inlet isolation valve and the trap equals atmospheric pressure (when the trap body temperature cools to room temperature). Do not remove the cap nut unless the trap is isolated from and is not subjected to steam pressure.
2. Hold the cover with one wrench and use another wrench to slowly loosen and remove the cap nut. Remove cap nut slowly to allow any residual pressurized steam to leak from the trap interior through the threads of the adjustment screw and the cover.
3. Hold the adjusting screw in place with a flat-head screwdriver and remove the locknut slowly in case of any additional steam leakage.
4. Use a flat-head screwdriver to turn the adjusting screw to adjust temperature. To raise the temperature setting, turn the adjusting screw counterclockwise. To lower the temperature setting, turn the adjusting screw clockwise. Refer to the set temperature adjustment chart for the number of turns required from the "0" position to reach the desired temperature.
5. After completing the adjustment, replace the locknut. Hold the adjusting screw in place with a flat-head screwdriver and tighten the locknut securely.
6. Replace the cap nut and tighten it to the proper torque (see page 9).
7. First fully open the outlet isolation valve, followed by then slowly opening the inlet isolation valve – carefully checking for any steam leaks that might occur. In the event steam leaks are detected, immediately close the inlet isolation valve, then the outlet isolation valve, and repair the source of leakage.
8. Check the temperature setting by observing an inline temperature sensor or by measuring the temperature at the wrench flat on the trap's inlet side at least 30 minutes after supplying steam with the new setting. The trap set temperature will be approximately 10 to 20 °C (20 to 40 °F) higher than the surface reading. If the resultant temperature is not as desired, repeat procedure from step 1 above.


Standard Factory Setting ("0" Position):

The standard "0" position is the position where point (A), the bottom of the adjusting screw slot is even with point (B), the top surface of the cap.


LEX3N-TZ
100 °C at 0.9 MPaG (9 barg), 212 °F at 130 psig



Temperature Setting Range





1 MPa = 10.197 kg/cm² = 10 bar



Set Temperature Adjustment Chart

The trap can be set to open at any temperature between 50 °C and 200 °C (120 °F and 390 °F) provided the set temperature is at least 15 °C (27 °F) below saturated steam temperature. To determine the number and direction of adjusting screw turns required for the desired set temperature, refer to the charts below.

1. Start at the standard factory setting (point A) (100 °C at 0.9 MPaG, 9 barg; 212 °F at 130 psig).
2. Move up or down vertically to the desired set temperature (point B).
3. Follow the set temperature line in either direction to the vertical line corresponding to the actual operating steam pressure (point C).
4. Follow the horizontal line to where it meets the left side of the chart (point D), indicating the number and direction of turns required. (- turn: clockwise, + turn: counterclockwise)




1 MPa = 10.197 kg/cm² = 10 bar

- turn: clockwise, + turn: counterclockwise

Standard "0" position = 100 °C at 0.9 MPaG, 9 barg; 212 °F at 130 psig

9. Cleaning Function

Rust, scale and other buildup on the valve seat may hinder the sealing ability of the steam trap and cause steam leakage and resultant higher product temperature; or block the valve seat opening - thereby preventing condensate discharge and resultant lowered product temperature. The LEX3N-TZ contains a built-in cleaning device that can be used without removing the trap from the line. Follow the steps below to remove contaminant accumulation from around the valve opening.



- To prevent possible injury, always relieve pressure from trap before opening to clean the trap.
- Always wear heat-insulated gloves and eye protection when handling products exposed to high temperatures. Failure to do so may result in burns.

Cleaning Function Instructions

1. First close the inlet isolation valve, followed by then closing the outlet isolation valve. Wait until the pressure between the inlet isolation valve and the trap equals atmospheric pressure (when the trap body temperature cools to room temperature). Do not remove the cap nut or the cover unless the trap is isolated from and is not subjected to steam pressure.
2. Hold the cover with one wrench and use another wrench to slowly loosen and remove the cap nut. Remove cap nut slowly to allow any residual pressurized steam to leak from the trap interior through the threads of the adjustment screw and the cover. If steam leakage occurs while loosening cap nut or locknut, disassemble the trap and replace both the seal ring and the cover gasket (see chapter 10).

Continued on the next page

3. Hold the adjusting screw in place with a flat-head screwdriver and remove the locknut slowly in case of any additional steam leakage.
4. Check the current set position of the adjusting screw. Check and record the number of turns required to return to the standard factory setting (when points (A) and (B) are even with each other as shown on page 5).
5. Use a flat-head screwdriver to slowly turn the adjusting screw clockwise (to tighten) until it stops. (This causes the cleaning edge of the stem to reach the valve seat and loosen debris).
6. Slowly turn the adjusting screw counterclockwise (to loosen) until it stops. (This will allow flushing once the steam is safely turned on using the instructions that follow).
7. Replace the cap nut and tighten it to the proper torque (see page 9).
8. First fully open the outlet isolation valve, and then slowly and carefully open the inlet isolation valve – checking for any steam leaks. In the event steam leaks are detected, immediately close the inlet isolation valve, then the outlet isolation valve, and repair the source of leakage.
9. Wait 10 seconds to allow any loose scale to be flushed internally. Be aware of any external steam leak – including the outlet connection if opened to atmosphere. Be careful to not come in contact with any steam that is discharging from an open outlet connection. If any steam leaks are detected elsewhere on the trap or piping, immediately close the inlet isolation valve, then the outlet isolation valve, and repair the source of leakage.
10. Next, prepare to set the trap temperature again by first isolating the trap and safely relieving all steam pressure from the trap as follows.
11. First close the inlet isolation valve, followed by then closing the outlet isolation valve. Wait until the inlet pressure equals atmospheric pressure. (When the trap body temperature cools to room temperature)
12. Hold the cover with one wrench and use another wrench to slowly remove the cap nut as in step 2 above.
13. Slowly turn the adjusting screw clockwise (to tighten) to return to the original position checked in step 4 above.
14. Replace the locknut. Hold the adjusting screw in place with a flat-head screwdriver and tighten the locknut securely.
15. Replace the cap nut and tighten it to the proper torque (see page 9).
16. First fully open the outlet isolation valve, followed by then slowly opening the inlet isolation valve – carefully checking for any steam leaks. In the event steam leaks are detected, immediately close the inlet isolation valve, then the outlet isolation valve, and repair the source of leakage.
17. Check the temperature setting by observing an inline temperature sensor or by measuring the temperature at the wrench flat on the trap's inlet side at least 30 minutes after supplying steam with the new setting. The trap set temperature will be approximately 10 to 20 °C (20 to 40 °F) higher than the temperature reading on the trap body surface. If the resultant temperature is not as desired, use the instructions for adjusting temperature settings (see page 5).

10. Inspection and Maintenance

Operational inspections should be performed at least twice per year, or as called for by trap operating conditions. Steam trap failure may result in temperature drop in the equipment, poor product quality or losses due to steam leakage.



CAUTION

- Installation, inspection, maintenance, repairs, disassembly, adjustment and valve opening/closing should be carried out only by trained maintenance personnel.
- Before attempting to open the trap, close the isolation valves and wait until the trap has cooled completely. Failure to do so may result in burns.
- Be sure to use the proper components and NEVER attempt to modify the product.

Parts Inspection Procedure	
Gasket(s)	Check for warping and damage
Seal Ring	Check for scratches and wear
Valve Stem	Check for scratches and wear
Bimetal Element	Check for wear and deformation
Over-expansion and Return Springs	Check for wear
Screen	Check for clogging, corrosion or damage
Valve Seat	Check for rust, scale, oil film wear or damage
Body, Cover	Check inside for rust and scale

Disassembly/Reassembly (to reassemble, follow procedures in reverse)		
Part & No.	During Disassembly	During Reassembly
Cap Nut 16	Remove with a spanner or socket wrench	Consult the table of tightening torques and tighten to the proper torque
Cap Nut Gasket 21	Remove and clean sealing surfaces	Replace with a new gasket if warped or damaged
Locknut 15	Remove with a spanner or socket wrench	Reattach and tighten
Cover 2	Remove with a spanner or socket wrench	Line up spring pin in valve stem with grooves cut into the adjusting screw as cover is placed onto the body; consult the table of tightening torques and tighten to the proper torque
Cover Gasket 17	Remove and clean sealing surfaces	Replace with a new gasket; coat surfaces with anti-seize
Adjusting Screw 4	Screw in by using a flat-head screwdriver	Be careful not to damage the seal ring during reassembly
Seal Ring 13	Remove	Replace with a new seal ring if damaged; coat with heat resistant silicon grease
Snap Ring 11	Remove from the valve stem	Reattach to the valve stem
Washer 6	Lift up and off from the valve stem	Slide onto the valve stem
Return Spring 10	Remove from the valve stem	Place on the valve stem
Thrust Plate 20	Remove from the valve stem by lifting up and off	Slide onto the valve stem
Washer (5 sets) 6	Lift up and off from the valve stem	Slide onto the valve stem
Bimetal Element (5 sets of 2 discs) 5	Remove the bimetal element from the valve stem by lifting up and off	Reassemble the bimetal elements, paying special attention to the proper orientation (the TLV marks on the outside, see Exploded View, p. 3)
Spring Pin 12	Remove from the valve stem only if damaged	Replace with new if damaged
Screen 14	Remove without bending	Reinsert without bending
Spring Guide 19	Remove from the trap body	Reinsert in the proper orientation
Overexpansion Spring 9	Remove from the trap body	Reinsert
Valve Seat 7	Remove with a socket wrench, being careful not to scratch the sealing surfaces	Consult the table of tightening torques and tighten to the proper torque; be careful not to scratch seating surfaces
Valve Seat Gasket 8	Remove and clean sealing surfaces	Replace with a new gasket; coat surfaces with anti-seize

Tightening Torque and Distance Across Flats

Part	Torque		Distance Across Flats	
	N-m	(lb-ft)	mm	(in)
Cap Nut	35	(26)	24	(¹⁵ / ₁₆)
Cover	250	(185)	46	(1 ¹³ / ₁₆)
Valve Seat	30	(22)	19	(³ / ₄)

NOTE: - Coat all threaded portions with anti-seize.

1 N-m ≈ 10 kg·cm

- If drawings or other special documentation were supplied for the product, any torque given there takes precedence over values shown here.

11. Troubleshooting

If the expected performance is unachievable after installation of the steam trap, read chapters 5 and 6 again and check the following points to take appropriate corrective measures.

Problem	Cause	Remedy
No condensate is discharged or temperature doesn't rise to the set temperature	A bimetal element is damaged or broken	Replace with a new bimetal element
	The assembly (orientation) of the bimetal elements is incorrect	Correct the assembly of the bimetal elements
	There is a build-up of foreign matter in the spaces between the bimetal elements	Clean the bimetal elements
	The valve seat is clogged with rust and scale	Use cleaning function
	The screen or piping are clogged with rust and scale	Clean parts
	The adjusting screw is not correctly positioned	Readjust the screw
Steam is blowing or the temperature rises above the set temperature	There is a build-up of dirt or scale on the valve stem or seating surfaces of the valve seat	Use cleaning function
	The valve stem is worn or sealing surfaces are damaged	Replace with a new valve stem
	The valve seat is worn or sealing surfaces are damaged	Replace with a new valve seat
	The valve seat is loose	Tighten to the proper torque
	The valve seat gasket is damaged	Replace with a new gasket
There is leakage to the outside of the trap	The adjusting screw is not correctly positioned	Readjust the screw
	Leakage from the cap nut gasket: the gasket or the seal ring is damaged or deteriorated	Replace with a new gasket or seal ring
	Leakage from the adjusting screw: the seal ring is damaged or deteriorated	Replace with a new seal ring
	Leakage from the cover gasket: the cover gasket is damaged or deteriorated	Replace with a new gasket

NOTE: When replacing parts with new, use the parts list on page 3 for reference, and replace with parts from the Maintenance Kit and/or Repair Kit. Please note that replacement parts are only available as part of a replacement parts kit.

12. TLV EXPRESS LIMITED WARRANTY

Subject to the limitations set forth below, TLV Corporation, a North Carolina corporation (“TLV”) warrants that products which are sold by it, TLV CO., LTD., a Japanese corporation (“TLVJ”) or TLV International, Inc., a Japanese corporation (“TII”), (hereinafter the “Products”) are designed and manufactured by TLVJ, conform to the specifications published by TLV for the corresponding part numbers (the “Specifications”) and are free from defective workmanship and materials. With regard to products or components manufactured by unrelated third parties (the “Components”), TLV provides no warranty other than the warranty from the third party manufacturer(s), if any.

Exceptions to Warranty

This warranty does not cover defects or failures caused by:

1. improper shipping, installation, use, handling, etc., by other than TLV or service representatives authorized by TLV; or
2. dirt, scale or rust, etc.; or
3. improper disassembly and reassembly, or inadequate inspection and maintenance by other than TLV or service representatives authorized by TLV; or
4. disasters or forces of nature or Acts of God; or
5. abuse, abnormal use, accidents or any other cause beyond the control of TLV; or
6. improper storage, maintenance or repair; or
7. operation of the Products not in accordance with instructions issued with the Products or with accepted industry practices; or
8. use for a purpose or in a manner for which the Products were not intended; or
9. use of the Products in a manner inconsistent with the Specifications; or
10. use of the Products with Hazardous Fluids (fluids other than steam, air, water, nitrogen, carbon dioxide and inert gases (helium, neon, argon, krypton, xenon and radon)); or
11. failure to follow the instructions contained in the TLV Instruction Manual for the Product.

Duration of Warranty

This warranty is effective for a period of the earlier of: (i) three (3) years after delivery of Products to the first end user in the case of sealed SST-Series Products for use in steam pressure service up to 650 psig; (ii) two (2) years after delivery of Products to the first end user in the case of PowerTrap® units; or (iii) one (1) year after delivery of Products to the first end user in the case of all other Products. Notwithstanding the foregoing, asserting a claim under this warranty must be brought by the earlier of one of the foregoing periods, as applicable, or within five (5) years after the date of delivery to the initial buyer if not sold initially to the first end user.

ANY IMPLIED WARRANTIES NOT NEGATED HEREBY WHICH MAY ARISE BY OPERATION OF LAW, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE AND ANY EXPRESS WARRANTIES NOT NEGATED HEREBY, ARE GIVEN SOLELY TO THE INITIAL BUYER AND ARE LIMITED IN DURATION TO ONE (1) YEAR FROM THE DATE OF SHIPMENT BY TLV.

Exclusive Remedy

THE EXCLUSIVE REMEDY UNDER THIS WARRANTY, UNDER ANY EXPRESS WARRANTY OR UNDER ANY IMPLIED WARRANTIES NOT NEGATED HEREBY (INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE), IS **REPLACEMENT**; PROVIDED: (a) THE CLAIMED DEFECT IS REPORTED TO TLV IN WRITING WITHIN THE APPLICABLE WARRANTY PERIOD, INCLUDING A DETAILED WRITTEN DESCRIPTION OF THE CLAIMED DEFECT AND HOW AND WHEN THE CLAIMED DEFECTIVE PRODUCT WAS USED; AND (b) THE CLAIMED DEFECTIVE PRODUCT AND A COPY OF THE PURCHASE INVOICE IS RETURNED TO TLV, FREIGHT AND TRANSPORTATION COSTS PREPAID, UNDER A RETURN MATERIAL AUTHORIZATION AND TRACKING NUMBER ISSUED BY TLV. ALL LABOR COSTS, SHIPPING COSTS, AND TRANSPORTATION COSTS ASSOCIATED WITH THE RETURN OR REPLACEMENT OF THE CLAIMED DEFECTIVE PRODUCT ARE SOLELY THE RESPONSIBILITY OF BUYER OR THE FIRST END USER. TLV RESERVES THE RIGHT TO INSPECT ON THE FIRST END USER'S SITE ANY PRODUCTS CLAIMED TO BE DEFECTIVE BEFORE ISSUING A RETURN MATERIAL AUTHORIZATION. SHOULD SUCH INSPECTION REVEAL, IN TLV'S REASONABLE DISCRETION, THAT THE

CLAIMED DEFECT IS NOT COVERED BY THIS WARRANTY, THE PARTY ASSERTING THIS WARRANTY SHALL PAY TLV FOR THE TIME AND EXPENSES RELATED TO SUCH ON-SITE INSPECTION.

Exclusion of Consequential and Incidental Damages

IT IS SPECIFICALLY ACKNOWLEDGED THAT THIS WARRANTY, ANY OTHER EXPRESS WARRANTY NOT NEGATED HEREBY, AND ANY IMPLIED WARRANTY NOT NEGATED HEREBY, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, DO NOT COVER, AND NEITHER TLV, TII NOR TLVJ WILL IN ANY EVENT BE LIABLE FOR, INCIDENTAL OR CONSEQUENTIAL DAMAGES, INCLUDING, BUT NOT LIMITED TO LOST PROFITS, THE COST OF DISASSEMBLY AND SHIPMENT OF THE DEFECTIVE PRODUCT, INJURY TO OTHER PROPERTY, DAMAGE TO BUYER'S OR THE FIRST END USER'S PRODUCT, DAMAGE TO BUYER'S OR THE FIRST END USER'S PROCESSES, LOSS OF USE, OR OTHER COMMERCIAL LOSSES. WHERE, DUE TO OPERATION OF LAW, CONSEQUENTIAL AND INCIDENTAL DAMAGES UNDER THIS WARRANTY, UNDER ANY OTHER EXPRESS WARRANTY NOT NEGATED HEREBY OR UNDER ANY IMPLIED WARRANTY NOT NEGATED HEREBY (INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE) CANNOT BE EXCLUDED, SUCH DAMAGES ARE EXPRESSLY LIMITED IN AMOUNT TO THE PURCHASE PRICE OF THE DEFECTIVE PRODUCT. THIS EXCLUSION OF CONSEQUENTIAL AND INCIDENTAL DAMAGES, AND THE PROVISION OF THIS WARRANTY LIMITING REMEDIES HEREUNDER TO REPLACEMENT, ARE INDEPENDENT PROVISIONS, AND ANY DETERMINATION THAT THE LIMITATION OF REMEDIES FAILS OF ITS ESSENTIAL PURPOSE OR ANY OTHER DETERMINATION THAT EITHER OF THE ABOVE REMEDIES IS UNENFORCEABLE, SHALL NOT BE CONSTRUED TO MAKE THE OTHER PROVISIONS UNENFORCEABLE.

Exclusion of Other Warranties

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, AND ALL OTHER WARRANTIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE EXPRESSLY DISCLAIMED.

Severability

Any provision of this warranty which is invalid, prohibited or unenforceable in any jurisdiction shall, as to such jurisdiction, be ineffective to the extent of such invalidity, prohibition or unenforceability without invalidating the remaining provisions hereof, and any such invalidity, prohibition or unenforceability in any such jurisdiction shall not invalidate or render unenforceable such provision in any other jurisdiction.

TLV CORPORATION

13901 South Lakes Drive, Charlotte, NC 28273-6790, U.S.A.

Tel: [1]-704-597-9070

Fax: [1]-704-583-1610

Printed on recycled paper.

PAC-65349-a

Rev. 4/2024 (M)