

ISO 9001
ISO 14001



Manufacturer

TLV CO., LTD.
Kakogawa, Japan
is approved by LRQA Ltd. to ISO 9001/14001



Special Documentation

Wet Steam Measurement Application Package

Vortex flowmeter
EF200F-C

Copyright © 2022 by TLV CO., LTD.
All rights reserved

Table of contents

1	About this document	4
1.1	Document function	4
1.2	Using this document	4
1.3	Symbols used	4
1.4	Documentation	5
2	Product features and availability	7
2.1	Product features	7
2.2	Availability	7
3	Commissioning	8
3.1	Orientation	8
3.2	Configuring the measuring device	8
4	Operation	12
4.1	Wet steam warning	12
4.2	Output variable correction	13
4.3	Configuring the wet steam warning for the switch output	13
4.4	Configuring wet steam measurement	16
5	Technical data	17
6	General principles	19
6.1	Steam quality	19
6.2	Two-phase flow	20
6.3	System efficiency	21
6.4	Safety risk	21
6.5	Wet steam measurement with EF200F-C	22
7	TLV EXPRESS LIMITED WARRANTY ...	23
8	Service	25

1 About this document

1.1 Document function

This document is part of the Operating Instructions and serves as a reference for application-specific parameters and notes.

It provides detailed information on:

- Every individual parameter in the operating menu
- Advanced technical specifications
- General principles and application tips

1.2 Using this document

1.2.1 Information on the document structure



Additional information regarding:

- The arrangement of the parameters, along with a short description, according to the Operation menu, Setup menu, Diagnostics menu: Operating Instructions
- Operating concept: Operating Instructions





1.3 Symbols used

1.3.1 Safety symbols

Symbol	Meaning
	DANGER! This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.
	WARNING! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.
	CAUTION! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or medium injury.
	NOTE! This symbol contains information on procedures and other facts which do not result in personal injury.

1.3.2 Symbols for certain types of information

Symbol	Meaning
	Tip Indicates additional information.
	Reference to documentation
	Reference to page
	Reference to graphic
	Notice or individual step to be observed
	Series of steps

Symbol	Meaning
	Result of a step
	Operation via local display
	Operation via operating tool
	Write-protected parameter

1.3.3 Symbols in graphics

Symbol	Meaning
1, 2, 3 ...	Item numbers
A, B, C, ...	Views
A-A, B-B, C-C, ...	Sections


1.4 Documentation

1.4.1 Device documentation

Detailed information about the device can be found in the Operating Instructions and the other documentation:

- Available for all device versions via:
 - Internet:

The information required to retrieve the documentation can be found on the nameplate of the device.

 This technical documentation applies to a particular instrument family and is not assigned to a specific device.

1.4.2 Standard documentation

This manual is Special Documentation and is not a substitute for the Operating Instructions supplied with the device. Refer to the Operating Instructions and other documentation for detailed information.

The Special Documentation is an integral part of the following Operating Instructions:

Measuring device	Documentation code
EF200F-C	172-65757m

1.4.3 Content and scope

This Special Documentation contains a description of the additional parameters and technical data that are provided with the Wet Steam Measurement application package. All the parameters that are not relevant for wet steam measurement are described in the Operating Instructions.

- The "Technical data" section describes technical specifications for wet steam measurement → See 5
- The "General principles" section provides general information about wet steam measurement → See 6

2 Product features and availability

2.1 Product features

2.1.1 Wet steam measurement application package

The Wet Steam Measurement application package complements the Wet Steam Detection application package in steam applications by providing quantitative steam quality measurement.

The application package offers:

- Steam quality as a direct measured value (local display/current output/HART)
- Diagnostics information that issues a warning when the steam quality drops below a limit value → See 6.1 in the range between 80 to 100 %
- Calculation of the following additional process variables:
 - Total mass flow¹⁾ (local display/current output/HART)
 - Condensate mass flow (local display/current output/HART)
 - Correction of the volume flow²⁾, mass flow and energy flow in the steam application

2.2 Availability

The Wet Steam Measurement application package is only available for:

- EF200F-C
- Nominal diameters: DN 25 to 300 (1 to 12")
- Order code for "Sensor version; DSC sensor; measuring tube",
 - Option "Mass; 316L; 316L (integrated temperature measurement)"
 - Option "Mass steam; 316L; 316L (integrated pressure/temperature measurement)"

If the Wet Steam Measurement application package was ordered for the flowmeter ex works, this package is available when the measuring device is delivered to the customer. The function is accessed via the operating interfaces of the measuring device.

Ways to check function availability in the measuring device:

1) Total mass flow = steam mass flow + condensate mass flow
2) Correction of the volume flow = correction of the primary volume flow in relation to condensate in a steam application (≠ corrected volume flow); corrected volume flow = volume flow in relation to reference conditions

3 Commissioning

NOTICE

Note the following before commissioning the Wet Steam Detection application package:

- ▶ Do not use in conjunction with the inlet run correction function.
- ▶ Take the specified inlet runs into account.
- ▶ Do not use in conjunction with a flow conditioner.

3.1 Orientation

The measuring device must be installed in the pipe as follows:




Fig. 1 Horizontal orientation, transmitter head down

A0015590

3.2 Configuring the measuring device


The Medium selection wizard can be used to set all the parameters that are needed to configure the measuring device for wet steam measurement.

Perform the following to configure the measuring device:

1. In the Select medium parameter (→ See 3.2), select the Steam option.
2. In the Steam calculation mode parameter (→ See 3.2), select the Automatic (p-/T-compensated) option.
 - ↳ The measuring device does not perform a wet steam calculation in the case of saturated steam.
3. In the Steam quality parameter (→ See 3.2), select the Calculated value option.
4. Enter a fixed value for steam quality in the Steam quality value parameter (→ See 3.2.1).
 - ↳ Desired value which the measuring device uses if calculation is not possible because the steam quality is not within the general parameters → See 5.
5. For measuring devices with integrated temperature measurement only
 - Activate pressure compensation → See 3.2.2 or set the process pressure → See 3.2.
 - ↳ It is recommended to always activate pressure compensation and to also set the process pressure so that measuring device can use the set process pressure if pressure compensation fails.


Navigation

"Setup" menu → Medium selection



Steam quality	→ See 3.2.1
Steam quality value	→ See 3.2.1


Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Select medium	–	Select medium type.	<ul style="list-style-type: none"> • Gas • Liquid • Steam 	Steam
Steam calculation mode	The Steam option is selected in the Select medium parameter parameter.	Select calculation mode of steam: based on saturated steam (T-compensated) or automatic detection (p-/T-compensated).	<ul style="list-style-type: none"> • Saturated steam (T-compensated) • Automatic (p-/T-compensated) 	Saturated steam (T-compensated)
Steam quality	<p>The following conditions are met:</p> <ul style="list-style-type: none"> • Order code for "Application package": <ul style="list-style-type: none"> – Option "Wet steam measurement" • The Steam option is selected in the Select medium parameter parameter. <p> The software options currently enabled are displayed in the Software option overview parameter.</p>	Select compensation mode for steam quality.	<ul style="list-style-type: none"> • Fixed value • Calculated value 	Fixed value
Steam quality value	<p>The following conditions are met:</p> <ul style="list-style-type: none"> • The Steam option is selected in the Select medium parameter parameter. • The Fixed value option is selected in the Steam quality parameter parameter. 	Enter fixed value for steam quality.	0 to 100 %	100 %

3.2.1 Setting the process pressure


Once the Steam option has been selected in the Select medium parameter, the process pressure present in the system must be set.

1. Call up the Medium selection wizard.
2. Enter the process pressure present in the system in the Fixed process pressure parameter (→ See 3.2).

 TLV recommends the use of active pressure compensation. This fully rules out the risk of measured errors due to pressure variations and incorrect entries
→ See 3.2.2.


Navigation
"Setup" menu → Medium selection


Parameter overview with brief description

Parameter	Prerequisite	Description	User entry	Factory setting
Fixed process pressure	<p>The following conditions are met:</p> <ul style="list-style-type: none"> • Order code for "Sensor version", <ul style="list-style-type: none"> – Option "Mass flow (integrated temperature measurement)" or – Option "Mass flow (integrated pressure/temperature measurement)" • In the External value parameter (→ See 3.2.2) the Pressure option is not selected. 	<p>Enter fixed value for process pressure.</p> <p>Dependency The unit is taken from the Pressure unit parameter.</p> <p> For detailed information on setting the parameter in steam applications, see the Special Documentation for the Wet Steam Detection and Wet Steam Measurement application package</p>	0 to 250 bar abs.	0 bar abs.

3.2.2 Activating pressure compensation

For measuring devices with integrated temperature measurement only


 Active pressure compensation can be performed to minimize the effect of pressure variations. The pressure can be read in via the current input or fieldbus systems.

 For detailed information on reading in the pressure, see the Operating Instructions for the device → See 1.4

1. Call up the External compensation submenu.
2. In the External value parameter (→ See 3.2.2), select the Pressure option.

Navigation

"Setup" menu → Advanced setup → External compensation



Parameter overview with brief description

Parameter	Description	Selection	Factory setting
External value	Assign variable from external device to process variable.	Pressure	Off

4 Operation


The measuring device calculates the steam quality in the background.

Once the Wet Steam Measurement application package has been successfully put into operation, the following measuring device functions can be used:

- Wet steam warning if steam quality is in the range from 80 to 100 % → See 4.1
- Correction of the volume flow, mass flow and energy flow → See 4.3
- Configuration of wet steam warning for the switch output
- Configuration of wet steam measurement

4.1 Wet steam warning

The wet steam warning function implemented in the measuring device makes it possible to display a configurable diagnostic message. The threshold for triggering the diagnostic message is set to 80 % steam quality at the factory but this setting can be changed by the customer.

As soon as the steam quality drops below 80 %, the diagnostic message  S872 Wet steam detected appears on the display. This warning message disappears as soon as the steam quality exceeds 82 %. The hysteresis is fixed at 2 % (factory setting) and cannot be changed.

Changing the threshold value

The range of adjustment for the threshold value is 0 to 100 %. The limitation is also due to the fact that the calculated value cannot reach 0 %.



NOTE!


In order to make the setting, the Calculated value option must be selected in the Steam quality parameter (7605).

Navigation:

Setup → Advanced setup → External compensation → Steam quality


1. Call up the Diagnostic limits submenu.
2. In the Steam quality limit parameter (→ See 4.1), enter a value from 0 to 100 %.

The diagnostic message  S872 Wet steam detected is assigned the diagnostic behavior Warning. The measuring device displays a warning and can be evaluated via the digital interface. It is possible to change the diagnostic behavior to Alarm. As a result if diagnostic message  S872 Wet steam detected is active, the current output adopts the configured failsafe mode.

 For detailed information on adapting the diagnostic behavior, see the Operating Instructions → See 1.4

Navigation

"Expert" menu → System → Diagnostic handling → Diagnostic limits



→

Parameter overview with brief description


Parameter	Prerequisite	Description	User entry	Factory setting
Steam quality limit	The following conditions are met: <ul style="list-style-type: none"> • The Steam option is selected in the Select medium parameter parameter. • The Calculated value option is selected in the Steam quality parameter parameter. 	Enter the threshold value for the steam quality which, if undershot, causes the measuring device to display a diagnostic message.	0 to 100 %	80 %

4.2 Output variable correction

The following measured variables are corrected with the Wet Steam Detection/ Measurement application package depending on the steam quality:

- Volume flow
- Mass flow
- Energy flow

The correction depends on the entry in the Steam quality parameter (7605) (→ See 3.2). If the Fixed value option is selected, the measuring device corrects the measured variables mentioned above with the Steam quality value parameter (→ See 3.2) (factory setting 100 %). If the Calculated value option is selected, the measuring device corrects the variables using the steam quality currently measured in the process.

 Information on the measured error if the Calculated value option is selected → See 5

4.3 Configuring the wet steam warning for the switch output

NOTE!

Compared with the fixed thresholds for the wet steam warning → See 4.1, the behavior of the wet steam warning can be individually configured so that it is assigned to the switch output.

One of the following options must be available in the measuring device:
 • Order code for "Output; input", "4-20mA HART, pul./freq./switch output"

Configure the wet steam warning with the values recommended by Endress+Hauser for typical steam applications.

Navigation:

Setup → Pulse/frequency/switch output

1. Specify the operating mode of the output.
 ↳ In the Operating mode parameter (→ See 4.3), the Switch option is selected.

2. Select the function for the switch output.
 - ↳ The Limit option is selected in the Switch output function parameter (→ See 4.3).
3. Select the process variable for the limit function.
 - ↳ In the Assign limit parameter (→ See 4.3), the Steam quality option is selected.
4. Enter the measured value for the switch-on value.
 - ↳ In the Switch-on value parameter (→ See 4.3), the value 85 % has been entered.
5. Enter the measured value for the switch-off value.
 - ↳ In the Switch-off value parameter (→ See 4.3), the value 95 % has been entered.
6. Enter the delay time for switching on the switch output.
 - ↳ In the Switch-on delay parameter (→ See 4.3), the value 0.0 s has been entered.
7. Enter the delay time for switching off the switch output.
 - ↳ In the Switch-off delay parameter (→ See 4.3), the value 0.0 s has been entered.
8. Specify the output behavior in the event of a device alarm.
 - ↳ The Open option is selected in the Failure mode parameter (→ See 4.3).
9. Invert the output signal.
 - ↳ In the Invert output signal parameter (→ See 4.3), the No option is selected.

The wet steam warning has now been configured for the switch output.

Navigation

"Setup" menu → Pulse/frequency/switch output

▶ Pulse/frequency/switch output	
Operating mode	→ See 4.3
Switch output function	→ See 4.3
Assign limit	→ See 4.3
Switch-on value	→ See 4.3
Switch-off value	→ See 4.3
Switch-on delay	→ See 4.3
Switch-off delay	→ See 4.3
Failure mode	→ See 4.3
Invert output signal	→ See 4.3

Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Operating mode	–	Define the output as a pulse, frequency or switch output.	<ul style="list-style-type: none"> • Pulse • Frequency • Switch 	Pulse
Switch output function	The Switch option is selected in the Operating mode parameter.	Select function for switch output.	<ul style="list-style-type: none"> • Off • On • Diagnostic behavior • Limit • Status 	Off
Assign limit	<ul style="list-style-type: none"> • The Switch option is selected in the Operating mode parameter. • The Limit option is selected in the Switch output function parameter. 	Select process variable for limit function.	<ul style="list-style-type: none"> • Volume flow • Corrected volume flow • Mass flow • Flow velocity • Temperature • Pressure • Calculated saturated steam pressure* • Steam quality • Total mass flow* • Energy flow* • Heat flow difference* • Reynolds number* • Totalizer 1 • Totalizer 2 • Totalizer 3 	Volume flow
Switch-on value	<ul style="list-style-type: none"> • In the Operating mode parameter, the Switch option is selected. • In the Switch output function parameter, the Limit option is selected. 	Enter measured value for the switch-on point.	Signed floating-point number	Country-specific: <ul style="list-style-type: none"> • 0 m³/h • 0 ft³/h
Switch-off value	<ul style="list-style-type: none"> • In the Operating mode parameter, the Switch option is selected. • In the Switch output function parameter, the Limit option is selected. 	Enter measured value for the switch-off point.	Signed floating-point number	Country-specific: <ul style="list-style-type: none"> • 0 m³/h • 0 ft³/h
Switch-on delay	<ul style="list-style-type: none"> • The Switch option is selected in the Operating mode parameter. • The Limit option is selected in the Switch output function parameter. 	Define delay for the switch-on of status output.	0.0 to 100.0 s	0.0 s
Switch-off delay	<ul style="list-style-type: none"> • The Switch option is selected in the Operating mode parameter. • The Limit option is selected in the Switch output function parameter. 	Define delay for the switch-off of status output.	0.0 to 100.0 s	0.0 s
Failure mode	–	Define output behavior in alarm condition.	<ul style="list-style-type: none"> • Actual status • Open • Closed 	Open
Invert output signal	–	Invert the output signal.	<ul style="list-style-type: none"> • No • Yes 	No


* Visibility depends on order options or device settings


4.4 Configuring wet steam measurement

The Wet Steam Measurement application package enables the following functions:


- Steam quality as a direct measured value on the local display/current output/HART
- Calculate and output the following additional process variables:
 - Total mass flow (1854) (on local display/current output/HART)
 - Condensate mass flow (1857) (on local display/current output/HART)
- Correction of the volume flow, mass flow and energy flow in the steam application
- Configurable diagnostic message that is displayed if the measuring device is outside the specified ranges of the process variables (factory setting Off)

The steam quality is derived from the vortex signal according to a patented signal processing method.

 For detailed information on the measured error and the valid ranges of the process variables: → See 5

If the process variables for determining the steam quality are outside the valid ranges, the measuring device displays the diagnostic message  S874 X% spec invalid and, in the standard configuration, performs a correction with a steam quality of 100 % (factory setting). It is possible to change this diagnostic behavior.

Example

To correct the measuring device with another steam quality if diagnostic message  S874 X% spec invalid is present, this can be done by changing the Steam quality value parameter (7630) accordingly to a value of 80 %, for example. (Navigation: Setup → Advanced setup → External compensation/calibration method)

The process variables to be output are corrected depending on the Steam quality parameter (→ See 3.2)⁶⁾:

- If the Fixed value option is selected, the variables are always corrected using the settings in the Steam quality value parameter (7630)
- If the Calculated value option is selected, the variables are always corrected on the basis of the steam quality calculated by the system, derived from the measured DSC sensor signal. The calculated steam quality is then also directly available as an output value.

6) Navigation: Setup menu → Advanced setup submenu → External compensation submenu

5 Technical data

The Wet Steam Measurement application package can be used for the following ranges:

SI units

DN [mm]	Velocity range in the measuring tube [m/s]	Steam quality [%]	Temperature range [°C]	Pressure range [bar abs.]
25 to 300	$5 \leq u \leq 50$	$80 \leq x \leq 100$	$82 < T < 320$	$0.5 < p < 100$

US units


DN [in]	Velocity range [ft/s]	Steam quality [%]	Temperature range [°F]	Pressure range [psi abs.]
1 to 12	$16.4 \leq u \leq 164$	$80 \leq x \leq 100$	$179 < T < 608$	$7.25 < p < 1450$

NOTICE

Outside the valid ranges, the volume flow, mass flow and energy flow are no longer corrected.

Outside the valid ranges, these output variables are corrected with the value saved in the Steam quality value parameter (factory setting: 100 %). (Navigation: Setup menu → Advanced setup submenu → External compensation submenu → Steam quality value parameter)

- This can be displayed with the configurable diagnostic message $\triangle S874 X\%$ spec invalid (factory settingOff).



A0034433

- A Maximum measured error
- B Steam quality
- 1 Positive error curve
- 2 Negative error curve

Maximum measured error ¹⁾:

Process variable	Measured error ²⁾
Volume flow	$\pm 3\% \text{ }^3$
Mass flow	$\pm 4\%$
Energy flow	$\pm 4\%$
Steam quality	-2 to 0 % if steam quality is 100 to 98 %
	$\pm 2\%$ if steam quality is 98 to 95 %
	$\pm 2.5\%$ if steam quality is 95 to 90 %
	$\pm 5\%$ if steam quality is 90 to 80 %

Process variable	Measured error ²⁾
	Repeatability of steam quality measurement 2 %
Total mass flow	± 11 %

- 1) In the event of wet steam in the range of 80 to 100 % steam quality for nominal diameters DN 25 to 100 (1 to 4") at a pressure of 2 to 11 bar abs.
- 2) All the data refer to a confidence interval of 95 % and the steam phase (without condensate)
- 3) If the volume flow is not corrected on the basis of the measured steam quality, as happens in devices that do not have a wet steam measurement application package, for example, a measured error of up to 7 % can be expected.



For additional information about measured errors, see the "Maximum measured error" section in the Technical Information document

6 General principles

The vortex flow measuring principle is a universal measuring principle that allows users to measure liquids, gases and steams. Thanks to its very robust design, the measuring device is the flowmeter of choice in steam applications. Boilers are used for industrial steam generation. Steam is the most efficient energy transfer medium. The two primary applications are the transfer of thermal energy (building heating, boiling and heating processes) and kinetic energy (turbines in power stations). The steam present immediately at the outlet of a boiler that does not have a superheater is in a saturated state and is known as saturated steam. This type of steam has a theoretical steam quality of 100 % ($x = 1$). In relation to a closed volume, saturated steam describes the state when the last droplet of water changed to gas. As soon as energy is withdrawn from this steam condensate forms. This heat transfer involves a lot of energy (latent enthalpy h_{fg}). Superheated steam is formed from saturated steam if the temperature is increased at a constant pressure or the pressure drops at a constant temperature.

6.1 Steam quality

Wet steam describes a two-phase mixture. Saturated steam and condensate are in thermodynamic equilibrium. A steam quality of 80 %, for instance, means that 80 % of the mass flow is in a gaseous state and 20 % in a liquid state.

The steam quality x is referenced to the mass flow. A steam quality of 50 % does not mean that half the pipe is filled with water.

6.1.1 Volumetric comparison

Steam quality is a mass ratio:

$$x = \dot{m}_{\text{steam}} : (\dot{m}_{\text{steam}} + \dot{m}_{\text{condensate}})$$

Example 1

In a closed volume, 80 % of the mass fraction is in the form of saturated steam and 20 % in the form of condensate (= 80 % steam quality). At 10 bar (145 psi) absolute pressure, the volume consists of 99.9 percentage volume saturated steam and 0.1 percentage volume condensate because the density of the condensate is 200 times greater than that of steam.

Example 2

At a pressure of 8 bar (116 psi) and a temperature of +170 ° C (+338 ° F), 4 000 kg (8 818.5 lb) of steam flow through a pipe (DN 100 (4")) per hour. The steam quality is 80 %. The steam flows at a velocity of 36 m/s (118.1 ft/s). Presuming that the flow involved is annular flow → See page 20 and that the velocity of the condensate is 2 m/s (6.6 ft/s), a volumetric comparative variable can be calculated. With a steam quality of 80 %, the resulting annular flow would have a thickness of 0.5 mm (0.02 in).

6.1.2 Mass compensation

Volume flow is the primary measuring signal used in the vortex meter measuring principle. The volume flow of the gas phase (primary phase) can be measured with sufficient accuracy using conventional vortex flowmeters. However most users are more interested in the mass flow or energy flow of the steam as the transfer or release of energy is the primary task in steam applications. Modern vortex flowmeters offer users gas phase compensation for such situations. In our previous example, mass compensation of the gas phase means that only 80 % of the total mass flow is measured.

This consequently results in problems when analyzing the energy of a client's process:

- The client has no information about the quality of the steam or process.
- The process is inefficient as only the mass flow of the primary phase can be factored into efficiency calculations.
- The absence of an indicator for the quality of the steam means that an efficiency or safety analysis must be based on assumptions, making the process unsafe as a result.

6.2 Two-phase flow

In flow measurement, "two-phase flow" occurs when a gas phase and a liquid phase are present at the same time.

There are 3 classifications for two-phase flows (depending on the steam quality, velocity of the primary phase, pressure and temperature):


- Channel flow
- Wavy flow
- Annular flow

6.2.1 Channel flow

The liquid phase stays at the bottom half of the pipe, while the gas phase flows over it at a higher flow velocity.

6.2.2 Wavy flow

The liquid phase stays at the bottom half of the pipe, while the gas phase causes waves to occur in the liquid (increasing the risk of steam and water hammer).




A0034430

Fig. 2 Wavy flow - steam, condensate

6.2.3 Annular flow

The liquid phase (condensate) is present in the form of an annular-shaped film on the pipe wall, while the gas phase flows through the middle of it.



A0034431

Fig.3 Annular flow - steam, condensate

6.3 System efficiency

For efficient energy transfer it must be ensured that the optimum steam state is provided for the individual application:

- Transfer of energy through a distribution system: slightly superheated steam
The heat transfer coefficient is lower than in the case of saturated steam → less heat loss
- Operation of a turbine (gas kinetic energy does the work): highly superheated steam
Dry steam → no liquid parts, therefore less risk of abrasion on the turbine blades.
- Transfer of energy to the process: saturated steam
The heat transfer coefficient is higher than in the case of superheated steam → most of the energy can be transferred to the process.

Once steam has been generated, it is distributed through pipes to the various processes. During this distribution process, make sure to keep heat loss to a minimum.

Reasons for heat loss:

- Poor insulation
- Long distribution routes

The proportion of heat lost directly affects the system efficiency. Boilers operated incorrectly drive down system efficiency. The steam produced is of a poorer quality and can therefore not store the same amount of energy as saturated steam (100 % steam quality). If the steam quality drops below 100 %, the steam is known as wet steam. This wet steam contains a lower latent enthalpy h_g in proportion to the steam quality that can be transferred to the process.

As a result, the poorer the quality of steam the lower the system efficiency.

6.4 Safety risk

Further to this wet steam is also a considerable safety risk. Large amounts of condensate can cause considerable damage in systems.

Typical risks presented by poor steam quality:

- Water hammer
- Steam hammer
- Frothover in the start-up phase

Danger	Description	Effect
Water hammer	Condensate fills up the entire pipe for a short time and travels through the pipe at the speed of the steam.	<ul style="list-style-type: none"> • Destroys pipes, valves, measuring technology equipment • Loud banging
Steam hammer	A certain volume of steam is trapped between condensate at both ends for a short while → A sudden phase change of the trapped steam produces a local vacuum and causes the condensate fronts to collide → Shock waves with pressures up to 160 bar (2320.6 psi) are generated	<ul style="list-style-type: none"> • Destroys pipes, valves, measuring technology equipment • Loud banging
Frothover in the start-up phase (priming or carryover)	In the start-up phase of a steam system, it must be ensured that the connected steam consumption processes do not draw in more steam than can be generated. If this does nevertheless happen, the boiler pressure falls. If the boiler pressure is too low, this causes a pull over the surface of the water → some of the liquid water enters the flow of steam	<ul style="list-style-type: none"> • Boiler starts up and shuts down frequently • In extreme situations boiler can explode (if heating pipes are exposed and low-water alarm is defective at the same time) • Frothover, corrosive boiler water destroys pipes, valves, measuring technology equipment • Loud banging

Therefore, the poorer the quality of steam the higher the safety risk.

The risk of water hammer or steam hammer increases with decreasing steam quality. For this reason condensate traps are used in modern steam systems. A condensate trap removes the condensate from the pipe and increases the quality of the steam.

6.5 Wet steam measurement with EF200F-C

6.5.1 EF200F-C: the steam expert

The Wet Steam Measurement application package in conjunction with active pressure compensation makes the EF200F-C device an expert for steam applications. In industrial process engineering, steam is one of the main heat transfer media. It is important for businesses to make energy transfer as efficient as possible. To properly size and assess efficient steam facilities, exact information about the total mass flow or energy flow is needed. Steam has different states. Knowledge of these states is essential for accurate and correct measurement. For this reason, the customer is asked to enter the steam state in conventional vortex flowmeters. In many cases, customers enter this information based on an assumption or a preference. EF200F-C is the first vortex flowmeter on the market that enables automatic steam measurement across all steam states. EF200F-C with wet steam measurement and active pressure compensation enables an accurate energy balance and gives users a unique opportunity to appraise their process quality.

6.5.2 Advantages over conventional process for determining steam quality

The current state of the art for determining steam quality uses sampling methods, usually in conjunction with throttling calorimeters. This process was first introduced as early as 1888 by Cecil Hobart Peabody.

Wet steam measurement with EF200F-C offers several clear advantages over this process:

- Continuous monitoring and measurement of the steam quality
- Continuous calculation of corrected measured variables that depend on the steam quality
- No additional manpower needed to determine the steam quality (2 people and roughly 3 h work time are generally needed for a single sample using the conventional method)
- As there is no need to open the process the safety risk is considerably lower.

7 TLV EXPRESS LIMITED WARRANTY

Subject to the limitations set forth below, TLV CO., LTD., a Japanese corporation (“**TLV**”), warrants that products which are sold by it, TLV International Inc. (“**TII**” of its group companies excluding TLV Corporation (a corporation of the United States of America), (hereinafter the “**Products**”) are designed and manufactured by TLV, conform to the specifications published by TLV for the corresponding part numbers (the “**Specifications**”) and are free from defective workmanship and materials. The party from whom the Products were purchased shall be known hereinafter as the “**Seller**”. With regard to products or components manufactured by unrelated third parties (the “**Components**”), TLV provides no warranty other than the warranty from the third party manufacturer(s), if any.

Exceptions to Warranty

This warranty does not cover defects or failures caused by:

1. improper shipping, installation, use, handling, etc., by persons other than TLV, TII or TLV group company personnel, or service representatives authorized by TLV; or
2. dirt, scale or rust, etc.; or
3. improper disassembly and reassembly, or inadequate inspection and maintenance by persons other than TLV or TLV group company personnel, or service representatives authorized by TLV; or
4. disasters or forces of nature or Acts of God; or
5. abuse, abnormal use, accidents or any other cause beyond the control of TLV, TII or TLV group companies; or
6. improper storage, maintenance or repair; or
7. operation of the Products not in accordance with instructions issued with the Products or with accepted industry practices; or
8. use for a purpose or in a manner for which the Products were not intended; or
9. use of the Products in a manner inconsistent with the Specifications; or
10. use of the Products with Hazardous Fluids (fluids other than steam, air, water, nitrogen, carbon dioxide and inert gases (helium, neon, argon, krypton, xenon and radon)); or
11. failure to follow the instructions contained in the TLV Instruction Manual for the Product.

Duration of Warranty

This warranty is effective for a period of one (1) year after delivery of Products to the first end user. Notwithstanding the foregoing, asserting a claim under this warranty must be brought within three (3) years after the date of delivery to the initial buyer if not sold initially to the first end user.

ANY IMPLIED WARRANTIES NOT NEGATED HEREBY WHICH MAY ARISE BY OPERATION OF LAW, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE AND ANY EXPRESS WARRANTIES NOT NEGATED HEREBY, ARE GIVEN SOLELY TO THE INITIAL BUYER AND ARE LIMITED IN DURATION TO ONE (1) YEAR FROM THE DATE OF SHIPMENT BY THE SELLER.

Exclusive Remedy

THE EXCLUSIVE REMEDY UNDER THIS WARRANTY, UNDER ANY EXPRESS WARRANTY OR UNDER ANY IMPLIED WARRANTIES NOT NEGATED HEREBY (INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE), IS **REPLACEMENT**; PROVIDED: (a) THE CLAIMED DEFECT IS REPORTED TO THE SELLER IN WRITING WITHIN THE WARRANTY PERIOD, INCLUDING A DETAILED WRITTEN

DESCRIPTION OF THE CLAIMED DEFECT AND HOW AND WHEN THE CLAIMED DEFECTIVE PRODUCT WAS USED; AND (b) THE CLAIMED DEFECTIVE PRODUCT AND A COPY OF THE PURCHASE INVOICE IS RETURNED TO THE SELLER, FREIGHT AND TRANSPORTATION COSTS PREPAID, UNDER A RETURN MATERIAL AUTHORIZATION AND TRACKING NUMBER ISSUED BY THE SELLER. ALL LABOR COSTS, SHIPPING COSTS, AND TRANSPORTATION COSTS ASSOCIATED WITH THE RETURN OR REPLACEMENT OF THE CLAIMED DEFECTIVE PRODUCT ARE SOLELY THE RESPONSIBILITY OF BUYER OR THE FIRST END USER. THE SELLER RESERVES THE RIGHT TO INSPECT ON THE FIRST END USER'S SITE ANY PRODUCTS CLAIMED TO BE DEFECTIVE BEFORE ISSUING A RETURN MATERIAL AUTHORIZATION. SHOULD SUCH INSPECTION REVEAL, IN THE SELLER'S REASONABLE DISCRETION, THAT THE CLAIMED DEFECT IS NOT COVERED BY THIS WARRANTY, THE PARTY ASSERTING THIS WARRANTY SHALL PAY THE SELLER FOR THE TIME AND EXPENSES RELATED TO SUCH ON-SITE INSPECTION.

Exclusion of Consequential and Incidental Damages

IT IS SPECIFICALLY ACKNOWLEDGED THAT THIS WARRANTY, ANY OTHER EXPRESS WARRANTY NOT NEGATED HEREBY, AND ANY IMPLIED WARRANTY NOT NEGATED HEREBY, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, DO NOT COVER, AND NEITHER TLV, TII NOR ITS TLV GROUP COMPANIES WILL IN ANY EVENT BE LIABLE FOR, INCIDENTAL OR CONSEQUENTIAL DAMAGES, INCLUDING, BUT NOT LIMITED TO LOST PROFITS, THE COST OF DISASSEMBLY AND SHIPMENT OF THE DEFECTIVE PRODUCT, INJURY TO OTHER PROPERTY, DAMAGE TO BUYER'S OR THE FIRST END USER'S PRODUCT, DAMAGE TO BUYER'S OR THE FIRST END USER'S PROCESSES, LOSS OF USE, OR OTHER COMMERCIAL LOSSES. WHERE, DUE TO OPERATION OF LAW, CONSEQUENTIAL AND INCIDENTAL DAMAGES UNDER THIS WARRANTY, UNDER ANY OTHER EXPRESS WARRANTY NOT NEGATED HEREBY OR UNDER ANY IMPLIED WARRANTY NOT NEGATED HEREBY (INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE) CANNOT BE EXCLUDED, SUCH DAMAGES ARE EXPRESSLY LIMITED IN AMOUNT TO THE PURCHASE PRICE OF THE DEFECTIVE PRODUCT. THIS EXCLUSION OF CONSEQUENTIAL AND INCIDENTAL DAMAGES, AND THE PROVISION OF THIS WARRANTY LIMITING REMEDIES HEREUNDER TO REPLACEMENT, ARE INDEPENDENT PROVISIONS, AND ANY DETERMINATION THAT THE LIMITATION OF REMEDIES FAILS OF ITS ESSENTIAL PURPOSE OR ANY OTHER DETERMINATION THAT EITHER OF THE ABOVE REMEDIES IS UNENFORCEABLE, SHALL NOT BE CONSTRUED TO MAKE THE OTHER PROVISIONS UNENFORCEABLE.

Exclusion of Other Warranties

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, AND ALL OTHER WARRANTIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE EXPRESSLY DISCLAIMED.

Severability

Any provision of this warranty which is invalid, prohibited or unenforceable in any jurisdiction shall, as to such jurisdiction, be ineffective to the extent of such invalidity, prohibition or unenforceability without invalidating the remaining provisions hereof, and any such invalidity, prohibition or unenforceability in any such jurisdiction shall not invalidate or render unenforceable such provision in any other jurisdiction.

8 Service

For Service or Technical Assistance: Contact your TLV representative or your regional TLV office.

In Europe:

TLV EURO ENGINEERING GmbH

Daimler-Benz-Straße 16-18, 74915 Waibstadt, **Germany**

Tel: [49]-(0)7263-9150-0
Fax: [49]-(0)7263-9150-50

TLV EURO ENGINEERING UK LTD.

Units 7 & 8, Furlong Business Park, Bishops Cleeve,
Gloucestershire GL52 8TW, **U.K.**

Tel: [44]-(0)1242-227223
Fax: [44]-(0)1242-223077

TLV EURO ENGINEERING FRANCE SARL

Parc d'Ariane 2, bât. C, 290 rue Ferdinand Perrier, 69800 Saint Priest,
France

Tel: [33]-(0)4-72482222
Fax: [33]-(0)4-72482220

In North America:

TLV CORPORATION

13901 South Lakes Drive, Charlotte, NC 28273-6790, **U.S.A.**

Tel: [1]-704-597-9070
Fax: [1]-704-583-1610

In Mexico and Latin America:

TLV ENGINEERING S. A. DE C.V.

Av. Jesús del Monte 39-B-1001, Col. Hda. de las Palmas, Huixquilucan,
Edo. de México, 52763, **Mexico**

Tel: [52]-55-5359-7949
Fax: [52]-55-5359-7585

In Oceania:

TLV PTY LIMITED

Unit 8, 137-145 Rooks Road, Nunawading, Victoria 3131, **Australia**

Tel: [61]-(0)3-9873 5610
Fax: [61]-(0)3-9873 5010

In East Asia:

TLV PTE LTD

36 Kaki Bukit Place, #02-01/02, **Singapore** 416214

Tel: [65]-6747 4600
Fax: [65]-6742 0345

TLV SHANGHAI CO., LTD.

5/F, Building 7, No.103 Caobao Road, Xuhui District, Shanghai, **China**
200233

Tel: [86]-(0)21-6482-8622
Fax: [86]-(0)21-6482-8623

TLV ENGINEERING SDN. BHD.

No.16, Jalan MJ14, Taman Industri Meranti Jaya, 47120 Puchong,
Selangor, **Malaysia**

Tel: [60]-3-8052-2928
Fax: [60]-3-8051-0899

TLV PRIVATE LIMITED

252/94 (K-L) 17th Floor, Muang Thai-Phatra Complex Tower B,
Rachadaphisek Road, Huaykwang, Bangkok 10310, **Thailand**

Tel: [66]-2-693-3799
Fax: [66]-2-693-3979

TLV INC.

#302-1 Bundang Technopark B, 723 Pangyo-ro, Bundang, Seongnam,
Gyeonggi, 13511, **Korea**

Tel: [82]-(0)31-726-2105
Fax: [82]-(0)31-726-2195

In the Middle East:

TLV ENGINEERING FZCO

Building 2W, No. M002, PO Box 371684, Dubai Airport Free Zone,
Dubai, **UAE**

Email: sales-me@tlv.co.jp

In Other Countries:

TLV INTERNATIONAL, INC.

881 Nagasuna, Noguchi, Kakogawa, Hyogo 675-8511, **Japan**

Tel: [81]-(0)79-427-1818
Fax: [81]-(0)79-425-1167

Manufacturer:

TLV CO., LTD.

881 Nagasuna, Noguchi, Kakogawa, Hyogo 675-8511, **Japan**

Tel: [81]-(0)79-427-1800
Fax: [81]-(0)79-422-2277