



Bellows Sealed Valve

Model BE3L

Keep this sheet in a safe place for future reference



Safety Considerations

- Read this section carefully before use and be sure to follow the instructions.
- Installation, inspection, maintenance, repairs, disassembly, adjustment, and valve opening/closing should be carried out only by trained maintenance personnel.
- The precautions listed in this manual are designed to ensure safety and prevent equipment damage and personal injury.
- The cautionary items below are very important for safety: be sure to observe all of them as they relate to installation, use, maintenance, and repair. Furthermore, TLV accepts no responsibility for any accidents or damage occurring as a result of failure to observe these precautions.

Symbol  Indicates that there is a possibility of injury or equipment / product damage.

	<p>Install properly and DO NOT use this product outside the recommended operating pressure, temperature and other specification ranges. Improper use may result in such hazards as damage to the product or malfunctions that may lead to serious accidents. Local regulations may restrict the use of this product to below the conditions quoted.</p>
	<p>Take measures to prevent people from coming into direct contact with product outlets. Failure to do so may result in burns or other injury from the discharge of fluids.</p>
	<p>When disassembling or removing the product, wait until the internal pressure equals atmospheric pressure and the surface of the product has cooled to room temperature. Disassembling or removing the product when it is hot or under pressure may lead to discharge of fluids, causing burns, other injuries or damage.</p>
	<p>NEVER attempt to modify the product in any way. (Repair parts are not supplied for this product. Please replace entire product.) Failure to observe these precautions may result in damage to the product and burns or other injury due to malfunction or the discharge of fluids.</p>
	<p>Do not use excessive force when tightening nuts and bolts on product flanges or when connecting threaded pipes to the product. Over-tightening may cause breakage leading to fluid discharge, which may cause burns or other injury.</p>
	<p>Use only under conditions in which no freeze-up will occur. Freezing may damage the product, leading to fluid discharge, which may cause burns or other injury.</p>
	<p>Use only under conditions in which no water hammer will occur. The impact of water hammer may damage the product, leading to fluid discharge, which may cause burns or other injury.</p>
	<p>Do not stand on or apply body weight to the handle. The handle may break, resulting in injury or other accident.</p>
	<p>Do not carry the product by the handle. The handle is not secured and may move causing injury.</p>
	<p>Do not place fingers inside the product. The handle may be turned resulting in injury.</p>

Specifications

Body Material	ASTM A105, DIN 1.0460
Valve Port	Reduced Port Globe Valve
Connection	Screwed, Socket Welded
Maximum Operating Pressure PMO	5.0 MPaG / 50 barg / 710 psig
Maximum Allowable Pressure PMA*	5.7 MPaG / 57 barg / 825 psig
Maximum Operating Temperature TMO	400 °C / 752 °F
Maximum Allowable Temperature TMA*	427 °C / 800 °F
Suitable Fluid**	Steam, Water, Heat Transfer Fluids, etc.

* Maximum allowable pressure (PMA) and maximum allowable temperature (TMA) are PRESSURE SHELL DESIGN CONDITIONS, **NOT** OPERATING CONDITIONS. (1 MPa=10.197 kg/cm²)

** Consult TLV for toxic, flammable, or otherwise hazardous fluids.

Specifications for option products may differ from specifications shown above. Contact TLV for details.

Installation & Operational Consideration

	<p>Before installing the product, blow out the piping to remove any piping scraps, dirt, oil and scales Failure to do so may result in a leakage at the seat due to foreign matter.</p>
	<p>Do not remove the product from its box or protective covering until just prior to installation. The protective cover keeps damage causing foreign materials out of the product.</p>
	<p>Do not attempt to turn the handle past the full open or full closed positions. Turning past these points may cause product malfunction or damage.</p>

(Repair parts are not supplied for this product. Contact TLV when the product is damaged.)

Product Warranty

1. Warranty Period
One year following product delivery.
2. Warranty Coverage
TLV CO., LTD. warrants this product to the original purchaser to be free from defective materials and workmanship. Under this warranty, the product will be repaired or replaced at our option, without charge for parts or labor.
3. This product warranty will not apply to cosmetic defects, nor to any product whose exterior has been damaged or defaced; nor does it apply in the following cases:
 - 1) Malfunctions due to improper installation, use, handling, etc., by other than TLV CO., LTD. authorized service representatives.
 - 2) Malfunctions due to dirt, scale, rust, etc.
 - 3) Malfunctions due to improper disassembly and reassembly, or inadequate inspection and maintenance by other than TLV CO., LTD. authorized service representatives.
 - 4) Malfunctions due to disasters or forces of nature.
 - 5) Accidents or malfunctions due to any other cause beyond the control of TLV CO., LTD.
4. Under no circumstances will TLV CO., LTD. be liable for consequential economic loss damage or consequential damage to property.

* * * * *

For Service or Technical Assistance: Contact your TLV representative or your regional TLV office.

TLV CO., LTD.

881 Nagasuna, Noguchi, Kakogawa, Hyogo 675-8511 JAPAN
Tel: 81-(0)79-422-1122 Fax: 81-(0)79-422-0112